




<p style="text-align: center;">HAVIT</p>  <p style="text-align: center;">I62 WIRELESS HEADPHONES</p> <p style="text-align: center;">USER MANUAL</p>	<p>Packing list:</p>  <p>Headphones *1</p> <p>TYPE-C Charging Cable*1</p> <p>User Manual*1</p> <p>Certificate of quality *1</p> <p>(The above picture is for reference only, specific to prevail in kind)</p> <p style="text-align: right;">1</p>	<p>Product structure:</p> <ol style="list-style-type: none"> 1.Power switch 2.Volume-/Previous 3.Volume+/Next 4.M button 5.AUX port 6.Indicator light 7.Type-c charging port 8.Microphone 9.SD card slot  <p style="text-align: right;">2</p>	<p>Power on Long press power switch for 3 seconds.</p> <p>Bluetooth connection ---Follow the steps (Please make sure that your phone is built-in Bluetooth function) 1.Hold down power switch for 3 seconds, then indicator alternately flashes blue and red , the headphones enter the pairing status. 2.Activate the Bluetooth function and search for "HAVIT I62" referring to your phone instructions. 3.Manually click "HAVIT I62" to connect. 4. The headphones can automatically connect the last device that you had paired. To re-connect, you just need to turn it on.</p> <p>Power off Long press power switch for 5 seconds to turn off.</p> <p>Answer incoming calls Short press power switch to answer incoming calls. Tip: Since some mobile phones default to answer calls via their own receiver, please refer to the instructions of your phone and set on your phone.</p> <p>End the current call Press power switch once to end the current call.</p> <p style="text-align: right;">3</p>
<p>Reject incoming calls Double press power switch to reject a call.</p> <p>Last number redials Double press power switch to redial the last calling number.</p> <p>Music playing 1.Play/Pause: Short press power switch; 2.PREV: Long press — to select the previous song; 3.NEXT: Long press + to select the next song; 4.VOL+ : Short press + to increase volume; (There will be a prompt when it reaches the maximum volume); 5. VOL-: Short press — to decrease volume.</p> <p>Wired mode: 3.5mm Audio Cable connecting To Audio Jack 1.Plug and play: Connecting the headphones to a music player with the provided 3.5mm audio cable, the headphones can be used as wired headphone without starting. 2.Compatible with mobile phone/iPod/MP4/MP3/C-D/PC,etc.</p> <p>Micro SD mode Insert a micro SD card and short press M button,</p> <p style="text-align: right;">4</p>	<p>the headphones will recognize (with a voice prompt) and automatically broadcasts MP3 format music in it.</p> <p>Voice assistant Double click the M button to activate the voice assistant.</p> <p>FM Operating Instructions 1.Short press the M button to choose FM mode; 2.Short press power switch to search channel; 3.Long press - and + to select the desired channels. Short press the - or + button to adjust the volume.</p> <p>To charge the headphones 1.As product is built-in non-removable and rechargeable battery, PLS use the provided charging cable to charge; 2.Charging voltage and current is 5V/1A. PLS charge the product with the input power below 5V/1A; 3.Fully charge the product before the first use. It takes 2.5 hours to charge for the subsequent use; 4.Charge if the LED lights up red, and LED turn blue upon charging finished.</p> <p style="text-align: right;">5</p>	<p>Notes a.Please choose the charger that is certified by the regular manufacturer; b.The battery performance may decrease as repeating charging and using the product. It's a normal phenomenon for all rechargeable batteries.</p> <p>Specification : Bluetooth Version: V5.3 Battery: 400mAh Play Time: 20H (60%Vol.) Charging Time: 2.5H Speaker Size: Φ40mm Input Voltage / Current: DC 5V/1A</p> <p>Warnings 1. Please follow the instruction to operate 2. Please charge the headphones with input power below 5V/1A, in order to protect the battery; 3. Please store or use the headphones in a normal temperature environment. 4. Please keep the headphones from heat source, such as radiators, hot air regulators, stoves, or other heat generating instruments. As it is not anti high temperature. 5. Don't jam the ports of the headphones,such as charger port, LED port and microphone etc.. 6. In order to protect your hearing and extend the</p> <p style="text-align: right;">6</p>	<p>speaker service life, it is not recommended to adjust the volume to the maximum level for a long time. 7. Whatever reasons damage the headphones, please feel free to contact our after-sales staff in time rather than repair by yourself. Otherwise, you will accept without after-sales service.</p> <p style="text-align: right;">7</p>